

This measurement for the new hole will be $13/16$ from center of existing hole to center of new hole, and on the centerline of the flange.

Mark both sides exactly the same and drill each side with a $15/32$ drill bit.

